

FIG. 1A




FIG. 1B

FIG. 1B is a perspective view of a slot machine cabinet 10b. The cabinet includes a top section with a display screen 32 and a control panel 30. The control panel features five reels 34 and a set of buttons 36. Below the control panel is a coin slot 12 and a coin return button 14. The main body of the cabinet is labeled 16, and the base is labeled 20. A coin tray 22 is located at the bottom. A coin hopper 24 is shown at the very bottom, with a coin 26 being dispensed. A coin door 28 is also visible.

FIG. 2A




FIG. 2B




FIG. 3

PAYS		Number of Cards Needed for Win
ROYAL FLUSH	- 1000 CREDITS	- 5 CARDS
STRAIGHT FLUSH	- 50 CREDITS	- 5 CARDS
4 OF A KIND	- 40 CREDITS	- 4 CARDS
FULL HOUSE	- 30 CREDITS	- 5 CARDS
FLUSH	- 20 CREDITS	- 5 CARDS
STRAIGHT	- 10 CREDITS	- 5 CARDS
3 OF A KIND	- 5 CREDITS	- 3 CARDS
2 PAIRS	- 3 CREDITS	- 4 CARDS
PAIR OF ACES	- 2 CREDITS	- 2 CARDS

FIG. 4A




FIG. 4B




FIG. 5A




FIG. 5B




FIG. 6A




FIG. 6B




FIG. 7A






30				
34a	34b	34c	34d	34e
				
HELD	HELD	HELD	HELD	HELD
INITIAL HAND-THREE OF A KIND				

FIG. 7B




FIG. 8A




FIG. 8B




FIG. 9A




FIG. 9B




FIG. 10

WAGERS	
INITIAL	- 1 CREDIT
1st REPLACED CARD	- 1 CREDIT
2nd REPLACED CARD	- 2 CREDITS
3rd REPLACED CARD	- 4 CREDITS
4th REPLACED CARD	- 8 CREDITS
5th REPLACED CARD	- 16 CREDITS
TOTAL FOR FIVE CARDS	- 32 CREDITS
NEGATIVE IMPACT CARD	- 16 CREDITS

FIG. 11

